



sartorius

mLINE®  
Mechanical  
Pipette

User Manual



# Contents

1. Intended use .....	2
2. Product description.....	2
3. Sartorius pipette tips.....	4
4. Unpacking.....	4
5. Personal identification .....	4
6. Pipette holder and carousel stand.....	5
6.1. Installing the pipette holder.....	5
6.2. Carousel stand .....	5
7. Calibration Tool .....	5
8. Operating the pipette.....	5
8.1. Setting the volume.....	5
8.2. Sealing and ejecting tips.....	6
8.3. Protective tip cone filters.....	6
9. Pipetting Techniques .....	7
9.1. Forward pipetting.....	7
9.2. Reverse pipetting.....	7
9.3. Repetitive reverse technique.....	8
10. Recommendations for Good Pipetting .....	8
11. Maintenance .....	8
11.1. Daily Cleaning of The Outer Surface of The Pipette.....	9
11.2. Cleaning The Lower Part of The Pipette.....	9
11.3. Sterilization of The Pipette.....	11
12. Testing the Performance and Recalibration.....	12
12.1. Testing the Performance.....	12
12.2. Recalibration.....	14
13. Troubleshooting.....	15
14. Warranty information .....	16
15. Performance specifications.....	17

Tell us what you think of  
Sartorius Pipettes and Tips  
[www.sartorius.com/lh-satisfaction](http://www.sartorius.com/lh-satisfaction)

# 1. Intended use



The Sartorius mLINE® pipette is intended, designed and manufactured for dispensing liquids in a variety of applications, and to be used in combination with Sartorius Optifit Tips or SafetySpace Filter Tips. The Sartorius pipette and tip combination, fall within the scope of in-vitro diagnostics, and can be used as a diagnostic medical device in related applications. Thereby, Sartorius mLINE® and Sartorius tips fulfil the relevant demands of the Directive 98/97/EC of the European Parliament.

The Sartorius mLINE® product range covers a volume range of 0.1 µl to 10 ml. It is recommended that Sartorius Optifit Tips or SafetySpace Filter Tips are used with Sartorius pipettes to ensure optimum compatibility and performance.

The Sartorius pipette is a general purpose laboratory device that fulfils ISO 9001 and ISO 13485 standards.

Read this user manual carefully before using the pipette for the first time. Additional copies can be downloaded from [www.sartorius.com](http://www.sartorius.com) or hardcopies ordered by email from [lhinfo.finland@sartorius.com](mailto:lhinfo.finland@sartorius.com).

**NOTE:** Prolonged pipetting can cause Work Related Upper Limb Disorder (WRULD). The manufacturer is not responsible for WRULD or any related injuries caused by using a pipette.



## 2. Product description

Your new mLINE is an autoclavable air displacement pipette. The attractive and ergonomical design of the mLINE pipette together with its very low pipetting forces reduce the risk of Work Related Upper Limb Disorder (WRULD). The pipette is designed for both right- and left-handed use.

**Note:** It is known that prolonged pipetting can cause WRULD. The manufacturer is not responsible for WRULD or any related diseases caused by prolonged pipetting.

The special tip cone design of the pipette offers the possibility to use replaceable Safe-Cone Filters to help prevent the contamination and

**Pipette description**



damage of the pipette. The operating button of the mLINE allows safe and easy filter ejection. The pipette uses disposable tips.

### 3. Sartorius pipette tips

Sartorius pipette tips are recommended for use with mLINE pipettes. The use of fully compatible tips will ensure the maximal pipetting accuracy and precision, and thereby guarantee the performance specifications given for the pipette. Sartorius tips are made of pure virgin polypropylene and manufactured in protected clean room conditions.



Sartorius offers a full range of standard Optifit, and SafetySpace™ Filter tips. Sartorius non-filter tips are available in trays, bulk packages and space-saving refill systems. Sartorius non-filtered tips and trays are autoclavable at 121°C (252F), 20 min, 1 bar (15 p.s.i). All Single Tray Racks and clean Refill Packs are certified RNase, DNase and endotoxin-free.

For more information, please go to [www.sartorius.com](http://www.sartorius.com) or contact your local Sartorius support.

### 4. Unpacking

The mLINE pipette package contains the following items:

1. Pipette
2. Calibration tool (also tube and ID window opener)
3. Pipette holder
4. Safe-Cone Filters (pipettes >10 µl)
5. Grease
6. Instruction manual
7. Performance certification in accordance with ISO 8655-6

Please check that all items are included and that no damage has occurred during shipment.

### 5. Personal identification

Each mLINE pipette can be identified with a tag located under the ID window which on the finger support.


1. Remove the ID window by using the calibration tool.

2. Remove the tag and mark the identifying information on it.
3. Position the tag in place and clip the window back into place.

## 6. Pipette holder and carousel stand

For convenience and safety, always keep the pipette vertically on its own holder or carousel stand when not in use.

Cat.No.	Product
LH-725630	Carousel Stand for 6 pipettes
LH-727640	Pipette Holder for 1 pipette
725620	Linear Stand



### 6.1. Installing the pipette holder

1. Clean the shelf surface with ethanol.
2. Remove the protective paper from the adhesive tape.
3. Install the holder by pressing it against the edge of the shelf.
4. Place the pipette onto the holder.

### 6.2. Carousel stand

A convenient and ergonomical Carousel stand for six mLINE pipettes is also available




## 7. Calibration Tool

(Tube and ID window opener)

The calibration tool is designed for the following purposes:

1. Tool for recalibration (A).
2. Opening tool for the ID window and lid of the calibration nut (B).
3. Opening tool for the tubes (C).



## 8. Operating the pipette

### 8.1. Setting the volume

The volume of the pipette is clearly shown through the display. The volume setting is carried out with the following steps:

1. Press the volume lock and hold it down.
2. Set the volume by rotating the operating



button (clockwise to decrease the volume and counterclockwise to increase).

3. Release the volume lock.


**Note:** Do not rotate the operating button without pressing down the volume lock. Do not rotate the operating button outside the volume range of the pipette.

## 8.2. Sealing and ejecting tips

To ensure the maximum accuracy and precision, Sartorius tips are recommended to be used with mLINE pipettes. Before fitting a tip ensure that the pipette tip cone is clean. Press the tip on the tip cone of the pipette. The pipette is provided with a spring loaded tip cone for optimal sealing.

Eject the tip by pressing the tip ejector with your thumb. Make sure that the tip is disposed into a suitable waste container.

**Note:** If the tip is pressed too hard the tip cone yields and, as a result, the counter and operating button moves.



## 8.3. Protective tip cone filters

The tip cone design of the mLINE pipettes (>10  $\mu$ l) allows the use of Safe-Cone Filters in the tip cones. These removable filters prevent liquids and aerosols from entering the pipette and thus, protects the pipette from contamination and damage.

The Safe-Cone Filters are available as Standard or Plus versions. It is recommended to use the Standard filter for general applications and the Plus filter for more demanding applications such as cell culture, bacterial and virological work and molecular biology. Filters need to be exchanged regularly. The interval for filter exchanging is application dependant but the recommendation is to change the filter daily (after 50 - 250 pipetting cycles) and always in case of over-aspiration. (See [www.sartorius.com](http://www.sartorius.com) for ordering information.)




The Safe-Cone Filters can be removed with the unique filter ejector without touching the filters by hand. Remove the operating button cap and eject the filter by pressing the operating button down. Make sure that the filter is disposed of into a suitable waste container. Clean the tip cone, if needed, and put the new filter in place.

## 9. Pipetting Techniques

Two basic pipetting techniques, forward and reverse pipetting, are associated with mLINE pipettes. Forward pipetting is the most common used pipetting technique. The technique employs the blow-out function ensuring complete delivery of the liquid. Reverse pipetting is recommended for highly viscous, biological or foaming liquids, or very small volumes of liquid. A selected volume plus an excess is aspirated into the tip. The delivery is done without blow-out, and, thus, the excess volume remains in the tip. The reverse technique also facilitates the repeated delivery of the same volume. If reverse pipetting technique is used the pipette might need recalibration.


### 9.1. Forward pipetting

1. Fit the tip onto the pipette tip cone.
2. Press the operating button to the first stop.
3. Place the tip just under the surface of the liquid (2-3 mm) and smoothly release the operating button up to the starting position. Wait one second. Carefully withdraw the tip from the liquid, touching against the edge of the container to remove excess from the outside of the tip.
4. Dispense the liquid by pressing the operating button to the first stop. After a short delay press the operating button to the second stop. This action will empty the tip.



### 9.2. Reverse pipetting

1. Fit the tip onto the pipette tip cone.
2. Press the operating button all the way to the second stop.
3. Place the tip just under the surface of the liquid (2-3 mm) and smoothly release the operating button up to the starting position.
4. Withdraw the tip from the liquid touching against the edge of the container to remove excess.
5. Press the operating button smoothly to the first stop to deliver the desired volume. Hold the operating button at the first stop. The liquid that remains in the tip should not be included in the delivery.
6. Discard the remaining liquid by pressing the operating button to the second stop.





### 9.3. Repetitive reverse technique

1. Follow the reverse technique steps 1 to 5.
2. Continue pipetting by repeating steps 3 to 5 as long as needed.
3. Finally discard the remaining liquid by pressing the operating button to the second stop.

## 10. Recommendations for Good Pipetting

- Make sure that the tip is firmly attached to the tip cone.
- Hold the pipette vertically when aspirating the liquid and place the tip only a few millimeters into the liquid.
- Always control the operating button slowly and smoothly.
- Pre-rinse the tip before aspirating the liquid by filling and emptying the tip for three to five times. This is important especially when pipetting liquids with a viscosity and density greater than water or liquids with high vapor pressure (e.g. ethanol).
- Check that the pipette, tip and liquid are at the same temperature.
- When pipetting liquids with temperatures different to the ambient temperature change the tip after each pipetting. Do not pre-rinse the tip.
- To avoid contamination, do not rest the pipette on its side especially with the tip attached.
- Change the tip cone filter regularly (recommendation after 50 - 250 pipetting cycles).
- Never strike the tip cone against the tip tray when mounting the tip as this can damage the pipette.
- Avoid rough handling and do not drop the pipette.
- Avoid exposing the unit to extreme temperature changes, humidity and dust (operating temperature from 15°C to 40°C).

## 11. Maintenance

mLINE pipettes have been designed for easy in-house service. If the pipette is used daily it is recommended to clean/decontaminate and check the performance of the pipette every three months. Sartorius also provides complete

repair and recalibration service for your pipette including a service report and performance certificate.

**Note:** Please make sure that the pipette has been decontaminated before you send it to us or your local representative. Please advise if any hazardous material has been used with your pipette.

**Note:** The use of the tip cone filters may prolong the service interval. Change the filters regularly.

**Note:** It is recommended to always use gloves when cleaning the pipette.

## 11.1. Daily Cleaning of The Outer Surface of The Pipette

Your mLINE pipette should be checked every day for cleanliness. To clean and decontaminate the outer surface of your pipette use ethanol (70%), isopropanol (60%) or a mild detergent and a soft lint-free cloth.

Gently clean the surface of the pipette with moistened cloth and wipe dry. Pay special attention to the tip cone. Change the tip cone filter if needed (Chapter 8.3.).

## 11.2. Cleaning The Lower Part of The Pipette

If your pipette is in daily use it is recommended to clean/decontaminate and grease the pipette every three months. It is recommended to send the multichannel pipettes to your local Sartorius service representative for cleaning and greasing. To clean and decontaminate the lower parts of the single channel pipette, follow these steps:

### Disassembling and cleaning

1. Eject the tip cone filter (if fitted, Chapter 8.3.)
2. Unscrew the tip ejector collar (1) counterclockwise and remove it.
3. Pipettes m3, m10, m20, m100, m200, m1000: Unscrew the tip cone holder (2) counterclockwise and carefully remove it with the tip cone (3).

Pipettes 5000 µl and 10 ml: Please note different opening method between these models.

Pipette 5000 µl:

Hold tip cone holder tightly      Rotate tip cone cylinder



Rotate tip cone holder      Hold tip cone cylinder tightly

Hold the tip cone holder firmly with your fingers and turn the tip cone cylinder counter clockwise with the other hand.

Pipette 10 ml:

Hold the tip cone cylinder firmly and turn the tip cone holder clockwise with your fingers.

**Note:** Don't turn the tip cone cylinder + holder system together. That will break the pipette!

4. Clean the tip ejector collar, the tip cone holder, the tip cone (cylinder) and the piston (5) with ethanol (70%), isopropanol (60%) or mild detergent and soft lint-free cloth.
5. Clean the interior of the tip ejector collar and the tip cone (cylinder) with a cotton swab. Be careful with the pipettes m3, m10, m20 and m100 so that the seal inside the tip cone will not damage.
6. Rinse the parts with distilled water if needed and let the parts dry.
7. Pipettes m3, m10, m20 and m100:  
Put a thin layer of grease on the piston (5).  
Pipettes m200 and m1000:  
Put a thin layer of grease around the seal (6).  
Pipettes m5000 and m10 ml:  
Put a thin layer of grease on the seal (6) and the interior of the tip cone cylinder (4).

**Note:** Avoid excess grease. Use only the grease provided with the pipette.

**Note:** Before reassembling check that no lint or particles are on the surface of the piston.

#### **Reassembling:**

1. Pipettes m3, m10, m20, m100, m200, m1000:  
Carefully place the tip cone (3) on the piston and attach it by screwing the tip cone holder (2) clockwise.  
Pipettes m5000 and m10 ml:  
Carefully place the tip cone cylinder (4) on the piston and screw clockwise. Make sure that the tip cone (cylinder) is properly tightened. Avoid over-tightening.
2. Attach the tip ejector collar (1) by screwing it clockwise.
3. Place the new tip cone filter on its place.
4. Press the operating button several times to ensure that the grease has spread evenly.
5. Check the performance of the pipette.

**Note:** It is always necessary to check the performance of the pipette after in-house service or maintenance.

### 11.3. Sterilization of The Pipette

The entire mLINE pipette can be sterilized by steam, autoclaving at 121°C, (252°F), 1 atm for 20 minutes. Remove the tip cone filter (if fitted, Chapter 8.3). The single channel pipettes can be autoclaved without special preparations. Unscrew the lower part of the multichannel pipettes by holding the connecting collar and turning the lower part 360° counterclockwise. Put the pipette into the sterilization bag and place it into the autoclave. After autoclaving, the pipette must be cooled down and left to dry overnight before use. Screw the lower part of the multichannel pipettes by holding the connecting collar and turning the lower part 360° clockwise. Make sure that the lower part is properly tightened. It is recommended to check the performance of the pipette after every autoclaving. It is also recommended to grease the piston/seal of the pipette after every 10 autoclaving.



## 12. Testing the Performance and Recalibration

It is recommended to check the performance of your mLINE pipettes regularly (e.g. every 3 months) and always after in-house maintenance. However, the user should establish a regular testing routine for their pipettes with regard to accuracy requirements of the application, frequency of use, number of operators using the pipette, nature of the liquid dispensed and the acceptable maximum permissible errors established by the user. (ISO 8655-1.)

### 12.1. Testing the Performance

Performance testing should take place in a draught-free room at 15 - 30°C, constant to +/- 0.5°C and humidity above 50%. The pipette, tips and the test water should have stood in the test room a sufficient time (at least 2 hours) to reach equilibrium with the room conditions. Use distilled or deionised water (grade 3, ISO 3696). Use an analytical balance with a readability of 0.01 mgs. (ISO 8655-6.)

#### **Weighing**

1. Adjust the desired test volume  $V_S$ .
2. Carefully fit the tip onto the tip cone.
3. Fill the tip with test water and expel to waste five times to reach a humidity equilibrium in the dead air volume.
4. Replace the tip. Pre-wet the tip by filling it once with test water and expel to waste.
5. Aspirate the test water, immersing the tip only 2-3 mm below the surface of the water. Keep the pipette vertical.
6. Withdraw the pipette vertically and touch the tip against the inside wall of the test water container.
7. Pipette the water into the weighing vessel, touching the tip against the inside wall of the vessel just above the liquid surface at an angle of 30° to 45°. Withdraw the pipette by drawing the tip 8-10 mm along the inner wall of the weighing vessel.
8. Read the weight in mgs ( $m_i$ ).
9. Repeat the test cycle until 10 measurements have been recorded.
10. Convert the recorded masses ( $m_i$ ) to volumes ( $V_i$ )  
 $V_i = m_i Z$        $Z =$  correction factor (Table 1)

11. Calculate the mean volume ( $\bar{V}$ ) delivered:  

$$\bar{V} = (\sum V_i)/10$$
12. For conformity evaluation calculate the systematic error  $e_s$  of the measurement:  
 in  $\mu\text{l}$ :  $e_s = \bar{V} - V_S$   $V_S$  = selected test volume  
 or in %:  $e_s = 100 (\bar{V} - V_S)/V_S$
13. For conformity evaluation calculate the random error of the measurement:  
 as standard deviation  $s = \sqrt{\frac{\sum (V_i - \bar{V})^2}{n - 1}}$   
 $n$  = number of measurement (10)  
 or as coefficient of variation  $CV = 100s/\bar{V}$
14. Compare the systematic error (inaccuracy) and random error (imprecision) with the values in the performance specifications - (p. 109) or the specifications of your own laboratory. If the results fall within the specifications, the pipette is ready for use. Otherwise check both systematic and random errors and, when necessary, proceed to the recalibration procedure (Chapter 12.2).

**Note:** Systemic error (inaccuracy) is the difference between the dispensed volume and the selected test volume. Random error (imprecision) is the scatter of the dispensed volumes around the mean of the dispensed volume. (ISO 8655-1.)

**Note:** Sartorius specifications are achieved in strictly controlled conditions (ISO 8655-6). The user should establish own specifications based on the field of use and the accuracy requirements placed on the pipette (ISO8655-1).

**Table 1**


Z-values ( $\mu\text{l}/\text{mg}$ ):

Temp. ( $^{\circ}\text{C}$ )	Air Pressure (kPa)			
	95	100	101.3	105
20.0	1.0028	1.0028	1.0029	1.0029
20.5	1.0029	1.0029	1.0030	1.0030
21.0	1.0030	1.0031	1.0031	1.0031
21.5	1.0031	1.0032	1.0032	1.0032
22.0	1.0032	1.0033	1.0033	1.0033
22.5	1.0033	1.0034	1.0034	1.0034
23.0	1.0034	1.0035	1.0035	1.0036
23.5	1.0036	1.0036	1.0036	1.0037

**Note:** This method is based on ISO 8655.

## 12.2. Recalibration

The calibration of your mLINE pipette has been factory-checked by using forward pipetting technique and certified at 22°C using grade 3 distilled water according to ISO 3696. The calibration is based on ISO 8655-6: Gravimetric test method for volumetric instruments. The pipette's specifications are guaranteed only with genuine Sartorius tips. If you find the pipette to be inaccurate after performance testing, please follow the instructions below:



1. Remove the lid of the calibration nut, located on the back of the handle, with the aid of the calibration tool.
2. Place the hexagonal head of the calibration tool into the hole of the calibration nut.
3. Turn the adjustment lock counterclockwise to decrease and clockwise to increase the volume.
4. Repeat testing the performance procedure (Chapter 12.1.). Continue until the results are correct.

**Note:** Recalibration is recommended if reverse pipetting technique is used.

**Note:** Sartorius offers accredited calibration service. Please contact your local Sartorius representative for further information.

# 13. Troubleshooting

Symptom	Possible cause	Solution
Droplets left inside the tip	Unsuitable tip	Use original Sartorius tips
Leakage or pipetted volume too small	Non uniform wetting of the plastic	Attach new tip
	Tip incorrectly attached	Attach firmly
	Unsuitable tip	Use original Sartorius tips
	Foreign particles between tip and cone	Clean the tip cone, attach new tip
	Tip cone holder incorrectly tightened	Tighten the tip cone holder
	Pipette damaged	Return to your Sartorius service representative for servicing
Pipette outside the established specifications	Incorrect operation	Follow instructions
	Unsuitable tip	Use original Sartorius tips
	Calibration altered	Recalibrate
Operating button jammed or moves erratically	Liquid has penetrated tip cone and dried	Clean and grease piston and seal Clean the tip cone
	Safe-Cone Filter has been contaminated	Change filter
	Insufficient amount of grease on a piston and seal	Grease accordingly
Tip ejector jammed or moves erratically	Tip ejector collar has been contaminated	Remove and clean ejector collar and tip cone



## 14. Warranty information

The mLINE pipettes are covered by warranty for 2 years against defects in materials and workmanship. Should your mLINE pipette fail to function at any time, please contact your local Sartorius representative.



ANY WARRANTY WILL, HOWEVER, BE DEEMED AS VOID IF FAULT IS FOUND TO HAVE BEEN CAUSED BY MALTREATMENT, MISUSE, UNAUTHORIZED MAINTENANCE OF SERVICE OR NEGLIGENCE OF REGULAR MAINTENANCE AND SERVICE, ACCIDENTAL DAMAGE, INCORRECT STORAGE OR USE OF THE PRODUCTS FOR OPERATIONS OUTSIDE THEIR SPECIFIED LIMITATIONS, OUTSIDE THEIR SPECIFICATIONS, CONTRARY TO THE INSTRUCTIONS GIVEN IN THIS MANUAL OR WITH OTHER THAN THE MANUFACTURER'S ORIGINAL TIPS.

Each mLINE pipette is tested before shipping by the manufacturer. The Sartorius Quality Assurance Procedure guarantees that the mLINE pipette you have purchased is ready for use.

# 15. Performance specifications

The manufacturer's specifications are guaranteed only when the manufacturer's original tips are used. The manufacturer's specifications should be used as guidelines when establishing your own performance specifications in accordance with ISO 8655.

## Performance Specifications and Order Information

mLINE®

Order Code	Channels	Volume Range ( $\mu$ l)	Increment ( $\mu$ l)	Test Volume ( $\mu$ l)	Systematic Error <sup>NI</sup> Limit $\pm$		Random Error <sup>NI</sup> Limit	
					(%)	( $\mu$ l)	(%)	( $\mu$ l)
725010	1	0.1 – 3	0.002	3	1.4	0.042	0.8	0.024
				1.5	2.6	0.039	1.6	0.024
				0.3	10.0	0.030	6.0	0.018
725020	1	0.5 – 10	0.01	10	1.0	0.100	0.6	0.060
				5	1.5	0.075	1.0	0.050
				1	3.0	0.030	2.0	0.020
725030	1	2 – 20	0.02	20	1.0	0.200	0.5	0.100
				10	1.4	0.140	0.9	0.090
				2	4.0	0.080	3.0	0.060
725050	1	10 – 100	0.10	100	0.8	0.80	0.2	0.20
				50	1.0	0.50	0.4	0.20
				10	3.0	0.30	1.0	0.10
728060	1	20 – 200	0.20	200	0.6	1.20	0.2	0.40
				100	0.8	0.80	0.3	0.30
				20	2.3	0.46	0.9	0.18
728070	1	100 – 1 000	1.00	1000	0.7	7.0	0.2	2.0
				500	0.8	4.0	0.2	1.0
				100	2.5	2.5	0.6	0.6
728080	1	500 – 5 000	10.0	5000	0.6	30	0.2	10
				2500	0.7	17.5	0.3	7.5
				500	2.4	12	0.6	3
728090	1	100 – 10 000	20.0	10000	0.6	60	0.2	20
				5000	1.2	60	0.3	15
				1000	3.0	30	0.6	6
728120	8	0.5 – 10	0.01	10	1.5	0.150	1.0	0.100
728220	12			5	2.5	0.125	2.0	0.100
1	5.5			0.055	4.0	0.040		
728130	8	10 – 100	0.10	100	0.9	0.90	0.4	0.40
728230	12			50	1.2	0.60	0.7	0.35
10	4.0			0.40	2.0	0.20		
728140	8	30 – 300	0.20	300	0.6	1.80	0.25	0.75
728240	12			150	1.0	1.50	0.5	0.75
30	2.5			0.75	1.0	0.30		

N Note: The listed systematic and random error values can be achieved only under strictly controlled conditions during type tests per ISO 8655. Due to the continuous product development by Sartorius, the systematic and random error values are subject to change without prior notice

# Contact Details



Sartorius Biohit Liquid Handling Oy  
Laippatie 1  
FI-00880 Helsinki  
Finland

Phone +358.755.951  
linfo.finland@sartorius.com  
www.sartorius.com

## Head Office

Sartorius Lab Instruments GmbH & Co. KG  
Otto-Brenner-Strasse 20  
37079 Göttingen  
Germany

Phone +49.551.308.0  
Fax +49.551.308.3289  
**www.sartorius.com**

Copyright by Sartorius, Helsinki, Finland.

All rights reserved. No part of this publication may be reprinted or translated in any form or by any means without the prior written permission of Sartorius.

The status of the information, specifications and illustrations in this manual is indicated by the date given aside.

Sartorius reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

All trademarks are Sartorius property unless otherwise stated. Patents granted or pending.